



















































	Original	Replacement		Original	Replacement
	Power		Power		Vol +
	Mute		Mute		Vol -
	1		1		Ok
	2		2		Up
	3		3		Down
	4		4		Right
	5		5		Left
	6		6		Menu
	7		7		Exit
	8		8		Sleep
	9		9		Format
	0		0		Rec
	Recall		Pre Ch		Red
	PR.List		List		Green
	Source		AV		Yellow
	CH+		Ch +		Blue
	CH-		Ch -		Options





Original	Replacement	Original	Replacement
Zoom/Tv/Radio	TV/R	Rec List	Shift + Subt
I/II/Audio	Dual		
Subtitle	Subt		
Info/Display	Info		
Step/Freeze	Back		
Prog/Index	Media		
A-B/Reveal	D. Menu		
Text/Eject	Text		
Play/Size	Play		
Pause/Subpage	Pause		
Stop/Hold	Stop		
I<<	I<<		
>>I	>>I		
<<	<<		
>>	>>		
S.Mode	Shift + Dual		
Pic.Mode	Shift + Format		

