

























Original		Replacement		Original		Replacement	
	Power		Power		Rakuten Tv		Yellow / YouTube / Repeat
	123		1				
	Colors		Green / APP / Repeat				
	Up		Up				
	Down		Down				
	Left		Left				
	Right		Right				
	Ok		OK				
	Back		Back / Return				
	Home		Menu / Home				
	Play/Pause		Play / Slow				
	Vol+		Vol+				
	Vol-		Vol-				
	CH+		CH+ / Page+				
	CH-		CH- / Page-				
	Netflix		Red / Netflix / Search				
	Prime video		Blue / Prime Video / Random				

