













































Original	Replacement	Original	Replacement
On/Off	 Power	OK Enter	 Ok
Mute	 Mute	Menu Right	 Right
Update	 +  Shift + Red	Menu Off	 Exit
Reveal	 +  Shift + Green	Menu Down	 Down
Txt Stop	 Stop	Back	 Back
Subt.List	 Subt	Volume+	 Vol +
Sleep Timer	 Sleep	Menu audio	 Dual
Info	 Info	Chan.Up	 Ch +
Menu video	 D. Menu	Volume-	 Vol -
Return TV	 +  Shift + Back	Chan.Down	 Ch -
Text	 Text	1	 1
Txt Expand	 Eject	2	 2
TV/AV	 AV	3	 3
Menu	 Menu	4	 4
Menu Up	 Up	5	 5
Display	 +  Shift + Info	6	 6
Menu Left	 Left	7	 7



Original	Replacement	
8		8
9		9
Guide -/-- 1.		Guide
0/10		0
2.Fav P/C 2.		Pre Ch
Red		Red
Green		Green
Yellow		Yellow
Bright+ Mode		Options
Blue		Blue
Rotate Text		Shift + Mute
Contrast+		Shift + Format
Tone-		3D
Mix Scan		List
Color- S.Std		Format
Game Coo		Shift + Smart
Level L		I<<

Original	Replacement	
Nicam/Mono		Shift + Dual
Level R/Woofer		>>
Aft/Caf		Smart
Store		Media
Search		TV/R
Tune-		Shift + Left
Tune+		Shift + Right
Contrast-		Shift + Ch -

