































































Original	Replacement	Original	Replacement
On/Off	 Power	OK Enter	 Ok
Mute	 Mute	Menu Right	 Right
Update	 I<<	Menu Off	 Exit
Reveal	 <<	Menu Down	 Down
Txt Stop	 Stop	Back	 Back
Info	 Info	Volume+	 Vol +
Subt.List	 Subt	Chan.Up	 Ch +
Sleep Timer	 Sleep	Volume-	 Vol -
Return TV	 TV/R	Menu audio	 Dual
Menu video	 D. Menu	Chan.Down	 Ch -
Text	 Text	1	 1
Txt Expand	 Eject	2	 2
TV/AV	 AV	3	 3
Menu	 Menu	4	 4
Menu Up	 Up	5	 5
Display	 +  Shift + Info	6	 6
Menu Left	 Left	7	 7



Original	Replacement	Original	Replacement
8	 8	Bright+ Mode	 Options
9	 9	Disp	 Rec
Guide -/-- 1.	 Guide	On/Tim	 List
0/10	 0	Bright- Sys	 3D
2.Fav P/C 2.	 Pre Ch	Store Text	 Shift + Text
Red	 Red	Audio-	 Shift + Down
Green	 Green	Audio+	 Shift + Up
Mix Scan	 >>	AV 2	 Shift + AV
Yellow	 Yellow	Tune-	 Shift + Left
Tone-	 >>	Tune+	 Shift + Right
Blue	 Blue	Contrast+	 Shift + Ch +
Rotate Text	 Shift + Mute	Search	 Shift + TV/R
Off/Tim	 Shift + List	Contrast-	 Shift + Ch -
Aft/Caf	 Play	Browse	 Media
Color+ P.Std	 Shift + Format	Color- S.Std	 Shift + Dual
Game Coo	 Smart	3.*	 Shift + Guide
Store	 Pause	4.# 16:9	 Format



Original	Replacement	Original	Replacement
Surround	 +  Shift + Red		
Nicam/Mono	 +  Shift + Green		
Level L	 +  Shift + Yellow		
Level R/Woofers	 +  Shift + Blue		

