





Original	Replacement
 Power	 Power
 OPC	 D.Menu / Top
 Sleep	 Sleep / Timer
 Dual Screen	 Shift + Red / Netflix /
 Select	 Shift + Green / APP /
 [i+]	 Info / Angle
 Aspect	 Picture / Format
 Dual Screen Size	 Shift + Yellow / YouTube /
 AV Mode	 Display / Media
 Rotate	 Setup / OPT /
 Dolby Virtual	 Smart / List
 3D-Y/C	 Shift + 3
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5

Original	Replacement
 6	 6
 7	 7
 8	 8
 9	 9
 Recall	 Back / Return
 0	 0
 -/--	 Guide / EPG / -/--
 [...]	 Subtitle / EQ
 [≡?]	 Play / Slow
 [≡i]	 Pause / Step / Freeze
 [≡]	 Text / Goto
 Sound	 Sound / Title
 Vol+	 Vol+
 P+	 CH+ / Page+
 Mute	 Mute / Dimmer
 Vol-	 Vol-
 P-	 CH- / Page-





Original	Replacement	Original	Replacement
 Input	 AV / Input / RDS		
 Menu	 Menu / Home		
 Up	 Up		
 Left	 Left		
 OK	 OK		
 Right	 Right		
 Exit	 Exit / Cancel / Clear		
 Down	 Down		
 Return	 Shift + Back / Return		
 Red	 Red / Netflix / Search		
 Green	 Green / APP / Repeat		
 Yellow	 Yellow / YouTube / Repeat		
 Blue	 Blue / Prime Video / Random		

Original	Replacement	Original	Replacement

