







































































Original		Replacement		Original		Replacement	
	Power		Power		8		8
	Mute		Mute		9		9
	Timer		Shift + AV		0		0
	Size		Format		-/--		Guide
	Timer / Cancel [≡X]		Exit		Index		Shift + Info
	Picture		Shift + Format		Red		Red
	Text / Mix		Text		Green		Green
	Input / Hold		AV		Yellow		Yellow
	Info / Reveal		Info		Blue		Blue
	Subtitle		Subt		Vol +		Vol +
	1		1		Vol -		Vol -
	2		2		Progr + / Page +		Ch +
	3		3		Progr - / Page -		Ch -
	4		4		<<		<<
	5		5		Play		Play
	6		6		>>		>>
	7		7		Stop		Stop



