





































































































Original	Replacement	Original	Replacement
 Power	 Power	 5	 5
 	 3D	 6	 6
	 Back	 7	 7
 SAT	 Smart	 8	 8
	 Mute	 9	 9
	 TV/R	 0	 0
	 Text		 Guide
	 AV	 C	 Exit
	 Shift + AV		 Shift + Stop
	 Options		 Up
	 List		 Vol +
	 Pre Ch		 Vol -
	 Shift + Pause		 Ch +
	 1		 Ch -
	 2		 Red
	 3		 Green
	 4		 Yellow























Original	Replacement	Original	Replacement
	Blue		Blue
	[≡?][ +]		Info
	↔◇		D. Menu
	[⊙]		Sleep
	■		Shift + Format
	Aspect		Format
	♪		Dual
	+		Right
	-		Left
	Menu		Menu
	OK		Ok
	Power Down		Shift + Power
	Prog+ Down		Shift + Ch +
	Prog- Down		Shift + Ch -
	<<		<<
	Play		Play
	>>		>>






















Original	Replacement	Original	Replacement
 Power Down	 Power		
 Prog+ Down	 Ch +		
 Prog- Down	 Ch -		
 Stop	 Stop		
 Pause	 Pause		
 Rec	 Rec		
 >>	 >>		
 Play	 Play		
 <<	 <<		

























Original		Replacement		Original		Replacement	
	Power Down		Power				
	Prog+ Down		Ch +				
	Prog- Down		Ch -				
	Stop		Stop				
	Pause		Pause				
	Rec		Rec				
	>>		>>				
	Play		Play				
	<<		<<				





Original	Replacement	Original	Replacement
 Power Down	 Power		
 Prog+ Down	 Ch +		
 Prog- Down	 Ch -		
 <<<	 <<<		
 Play	 Play		
 >>>	 >>>		
 Stop	 Stop		
 Pause	 Pause		
 Rec	 Rec		

