







































































Original	Replacement	Original	Replacement
 Power	 Power	 C	 Pre Ch
 Mute	 Mute	 [*]	 TV/R
 []	 Smart	 [↔*]	 Subt
 [≡]	 Text	 [↑*]	 List
 Input	 AV	 [↑]	 Options
 Output	 Media	 Red	 Red
 1	 1	 Green	 Green
 2	 2	 Yellow	 Yellow
 3	 3	 Blue	 Blue
 4	 4	 [≡+]	 3D
 5	 5	 [+]	 Info
 6	 6	 SAT	 Back
 7	 7	 Prog+	 Ch +
 8	 8	 Prog-	 Ch -
 9	 9	 Vol+	 Vol +
 0	 0	 Vol-	 Vol -
 -/--	 Guide	 Picture	 Format





Original	Replacement
	 Dual
	 Left
	 Up
	 Down
	 Menu
	 Ok
	 Shift + Power
	 >>
	 Play
	 <<
	 Stop
	 Pause
	 Shift + Ch +
	 Shift + Ch -

Original	Replacement



[illegible]

[illegible]

[illegible]