




Original	Replacement
 Power	 Power
 Eject/Open/Close	 Eject / Surround
 CD/DVD	 Shift + 2
 VCR	 Shift + 4
 FM/AM	 Shift + 6
 AUX	 Shift + 7
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 AV	 AV / Input / RDS
 7	 7
 8	 8
 9	 9
 0	 0

Original	Replacement
 Program	 TV/Radio /
 Clear	 Exit / Cancel / Clear
 Sound Mode	 Sound / Title
 Audio	 Audio / Lang I/II
 Show View	 Smart / List
 RDS	 Picture / Format
 Display/CLK/CN	 Display / Media
 PR/TRK/Preset Up	 Up
 Set Up/i	 Setup / OPT /
 Left/Tuning-	 Left
 OK/Memory/Ent	 OK
 Right/Tuning+	 Right
 Return	 Back / Return
 PR/TRK/Preset	 Down
 Disc menu	 D.Menu / Top
 Volume+	 Vol+
 Rec/ITR	 Rec / Rec Mode





Original	Replacement	Original	Replacement
I<</Backward	I<< / Preset-		
>>/Forward	>>I / Preset+		
Stop	Stop / Hold		
Pause/Step	Pause / Step / Freeze		
Play	Play / Slow		
Volume-	Vol-		
Marker	Fav / Marker / PC		
Search	Red / Netflix / Search		
S-Title	Subtitle / EQ		
Mute	Mute / Dimmer		
Angle/CM Skip	Info / Angle		
Repeat A-B/Speed	Yellow / YouTube / Repeat		
Repeat	Green / APP / Repeat		
Tv/VCR	Shift + TV/Radio / Program		
Random	Blue / Prime Video / Random		
Title	Shift + Sound / Title		
Zoom	Zoom / Size		





Original	Replacement
 Power	 Power
 Eject/Open/Close	 Eject / Surround
 CD/DVD	 Shift + 2
 VCR	 Shift + 4
 FM/AM	 Shift + 6
 AUX	 Shift + 7
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 AV	 AV / Input / RDS
 7	 7
 8	 8
 9	 9
 0	 0

Original	Replacement
 Program	 TV/Radio /
 Clear	 Exit / Cancel / Clear
 Sound Mode	 Sound / Title
 Audio	 Audio / Lang I/II
 Show View	 Smart / List
 RDS	 Picture / Format
 Display/CLK/CN	 Display / Media
 PR/TRK/Preset Up	 Up
 Set Up/i	 Setup / OPT /
 Left/Tuning-	 Left
 OK/Memory/Ent	 OK
 Right/Tuning+	 Right
 Return	 Back / Return
 PR/TRK/Preset	 Down
 Disc Menu	 D.Menu / Top
 Volume+	 Vol+
 Rec/ITR	 Rec / Rec Mode





Original	Replacement	Original	Replacement
I<</Backward	I<< / Preset-		
>>I/Forward	>>I / Preset+		
Stop	Stop / Hold		
Pause/Step	Pause / Step / Freeze		
Play	Play / Slow		
Volume-	Vol-		
Marker	Fav / Marker / PC		
Search	Red / Netflix / Search		
S-Title	Subtitle / EQ		
Mute	Mute / Dimmer		
Angle/CM Skip	Info / Angle		
Repeat A-B/Speed	Yellow / YouTube / Repeat		
Repeat	Green / APP / Repeat		
TV/VCR	Shift + TV/Radio / Program		
Random	Blue / Prime Video / Random		
Title	Shift + Sound / Title		
Zoom	Zoom / Size		

