





























	Original	Replacement		Original	Replacement
	Timer	 AV			
	Timer	 Up			
	Timer	 Sleep			
	1	 1			
	1	 Left			
	1	 Power			
	0	 0			
	0	 Ok			
	0	 Shift + Power			
	↻ Swing	 Smart			
	↻ Swing	 Right			
	~	 Media			
	~	 Down			

