































































Original	Replacement	Original	Replacement
 Power TV	 Power	 Test	 Text
 Home Theater	 Media	 Delay	 Format
 Home Theater	 Smart	 Level	 3D
 Tape	 Red	 -	 Ch -
 CD	 Yellow	 +	 Ch +
 Tuner/Band	 Green	 1 Tv	 1
 DVD	 Blue	 2 Tv	 2
 Up	 Up	 3 Tv	 3
 Left	 Left	 4 Tv	 4
 Select	 Ok	 5 Tv	 5
 Right	 Right	 6 Tv	 6
 Down	 Down	 7 Tv	 7
 Display	 Info	 8 Tv	 8
 Menu	 Menu	 9 Tv	 9
 Stereo	 Dual	 0 Tv	 0
 Surround	 Subt	 >10 Tv	 Guide
 SFC	 Options	 CH-	 Shift + Ch -
















































Original	Replacement
 CH+	 Shift + Ch +
 Tv/Video	 AV
 Disc/Deck 1/2	 D. Menu
 Muting	 Mute
 Vol-	 Vol -
 Vol+	 Vol +

Original	Replacement







Original	Replacement	Original	Replacement
 Power DVD	 Power	 Menu	 Menu
 Home Theater	 Media	 Stereo	 Dual
 Home Theater	 Smart	 Surround	 Subt
 Tape	 Red	 SFC	 Options
 CD	 Yellow	 Test	 Text
 Tuner/Band	 Green	 Delay	 Format
 DVD	 Blue	 Level	 3D
 Play DVD	 Play	 -	 Ch -
 I<</<< DVD	 <<	 +	 Ch +
 Stop DVD	 Stop	 1 DVD	 1
 >>/>>I DVD	 >>	 2 DVD	 2
 Up	 Up	 3 DVD	 3
 Left	 Left	 4 DVD	 4
 Select	 Ok	 5 DVD	 5
 Right	 Right	 6 DVD	 6
 Down	 Down	 7 DVD	 7
 Display	 Info	 8 DVD	 8





Original	Replacement
9 DVD	9
0 DVD	0
>10 DVD	Guide
CH-	Shift + Ch -
CH+	Shift + Ch +
Disc/Deck 1/2	List
Muting	Mute
Vol-	Vol -
Vol+	Vol +

Original	Replacement







Original	Replacement
 Power CD	 Power
 Power Tape	 +  Shift + Power
 Home Theater	 Media
 Home Theater	 Smart
 Tape	 Red
 CD	 Yellow
 Tuner/Band	 Green
 DVD	 Blue
 Play Tape	 +  Shift + Play
 Play CD	 Play
 I<</<< Tape	 +  Shift + <<
 I<</<< CD	 <<
 Stop Tape	 +  Shift + Stop
 Stop CD	 Stop
 >>/>>I Tape	 +  Shift + >>
 >>/>>I CD	 >>
 Up	 Up

Original	Replacement
 Left	 Left
 Select	 Ok
 Right	 Right
 Down	 Down
 Display	 Info
 Menu	 Menu
 Stereo	 Dual
 Surround	 Subt
 SFC	 Options
 Test	 Text
 Delay	 Format
 Level	 3D
 -	 Ch -
 +	 Ch +
 Direct Tuning/Disc Enter	 D. Menu
 1 CD-Tape	 1
 2 CD-Tape	 2









	Original	Replacement		Original	Replacement
	3 CD-Tape	 3			
	4 CD-Tape	 4			
	5 CD-Tape	 5			
	6 CD-Tape	 6			
	7 CD-Tape	 7			
	8 CD-Tape	 8			
	9 CD-Tape	 9			
	0 CD-Tape	 0			
	>10 CD-Tape	 Guide			
	CH-	 Shift + Ch -			
	CH+	 Shift + Ch +			
	Disc/Deck 1/2	 List			
	Disc/Deck 1/2	 Shift + List			
	Muting	 Mute			
	Vol-	 Vol -			
	Vol+	 Vol +			







Original	Replacement	Original	Replacement
 Power VCR	 Power	 Display	 Info
 Power Tuner/Band	 Shift + Power	 Menu	 Menu
 Home Theater	 Media	 Stereo	 Dual
 Home Theater	 Smart	 Surround	 Subt
 Tape	 Red	 SFC	 Options
 CD	 Yellow	 Test	 Text
 Tuner/Band	 Green	 Delay	 Format
 DVD	 Blue	 Level	 3D
 Play	 Play	 -	 Ch -
 I<</<<	 <<	 +	 Ch +
 Stop	 Stop	 Direct Tuning/Disc Enter	 D. Menu
 >>/>>I	 >>	 1 VCR	 1
 Up	 Up	 1 Tuner/Band	 Shift + 1
 Left	 Left	 2 VCR	 2
 Select	 Ok	 >10 VCR	 Guide
 Right	 Right	 2 Tuner/Band	 Shift + 2
 Down	 Down	 3 VCR	 3





Original	Replacement	Original	Replacement
 3 Tuner/Band	 +  Shift + 3	 Disc/Deck 1/2	 List
 4 VCR	 4	 Muting	 Mute
 4 Tuner/Band	 +  Shift + 4	 Vol-	 Vol -
 5 VCR	 5	 Vol+	 Vol +
 5 Tuner/Band	 +  Shift + 5	 >10	 +  Shift + Guide
 6 VCR	 6		
 6 Tuner/Band	 +  Shift + 6		
 7 VCR	 7		
 7 Tuner/Band	 +  Shift + 7		
 8 VCR	 8		
 8 Tuner/Band	 +  Shift + 8		
 9 VCR	 9		
 9 Tuner/Band	 +  Shift + 9		
 0 VCR	 0		
 0 Tuner/Band	 +  Shift + 0		
 CH-	 +  Shift + Ch -		
 CH+	 +  Shift + Ch +		

