



| Original | Replacement | Original | Replacement |
|---|-------------|---|---------------|
|  | Power |  | Power |
|  | Tv/R |  | TV/R |
|  | Input |  | AV |
|  | Mute |  | Mute |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | -/-- |  | Shift + Guide |
|  | Exit |  | Exit |
|  | Menu |  | Menu |
|  | P+ |  | Ch + |
|  | P- |  | Ch - |
|  | Vol+ |  | Vol + |
|  | Vol- |  | Vol - |
|  | Up |  | Up |
|  | Down |  | Down |
|  | Right |  | Right |
|  | Left |  | Left |
|  | OK |  | Ok |
|  | i |  | Info |
|  | Audio |  | Dual |
|  | Sub |  | Subt |
|  | Guide |  | Guide |
|  | TXT |  | Text |
|  | Back |  | Back |
|  | Pause |  | Pause |
|  | F1 |  | List |





| Original | Replacement | Original | Replacement |
|---|-------------|---|---------------|
|  | Power |  | Power |
|  | TV/R |  | TV/R |
|  | Source |  | AV |
|  | Mute |  | Mute |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | -/-- |  | Shift + Guide |
|  | Menu |  | Menu |
|  | Exit |  | Exit |
|  | P+ |  | Ch + |
|  | P- |  | Ch - |
|  | V+ |  | Vol + |
|  | V- |  | Vol - |
|  | Up |  | Up |
|  | Down |  | Down |
|  | Right |  | Right |
|  | Left |  | Left |
|  | OK |  | Ok |
|  | i |  | Info |
|  | Audio |  | Dual |
|  | Sub |  | Subt |
|  | Guide |  | Guide |
|  | TXT |  | Text |
|  | ↔ |  | Back |
|  | Pause |  | Pause |
|  | F1 |  | Options |



