







































































| Original  |            | Replacement   |                           | Original  |         | Replacement   |                               |
|---|------------|---|---------------------------|---|---------|---|-------------------------------|
|    | Power      |    | Power                     |    | 9       |    | 9                             |
|    | Top Menu   |    | Shift + D.Menu / Top Menu |    | AD      |    | Audio / Lang I/II             |
|    | DVD Menu   |    | D.Menu / Top              |    | 0       |    | 0                             |
|    | Tv/DVD     |    | TV/Radio /                |    | ATV/DTV |    | Shift + AV / Input / RDS      |
|    | Open/Close |    | Eject / Surround          |    | Guide   |    | Guide / EPG / -/-             |
|    | ▼          |    | Shift + Down              |    | Input   |    | AV / Input / RDS              |
|    | O/I/II     |    | Display / Media           |    | Menu    |    | Menu / Home                   |
|    | Subtitle   |    | Subtitle / EQ             |    | Quick   |    | Shift + Exit / Cancel / Clear |
|    | Text/Angle |    | Text / Goto               |    | Up      |    | Up                            |
|    | 1          |    | 1                         |    | Left    |    | Left                          |
|   | 2          |   | 2                         |   | OK      |   | OK                            |
|  | 3          |  | 3                         |  | Right   |  | Right                         |
|  | 4          |  | 4                         |  | Down    |  | Down                          |
|  | 5          |  | 5                         |  | Exit    |  | Exit / Cancel / Clear         |
|  | 6          |  | 6                         |  | Jump    |  | Smart / List                  |
|  | 7          |  | 7                         |  | Return  |  | Back / Return                 |
|  | 8          |  | 8                         |  | Setup   |  | Setup / OPT /                 |





| Original | Replacement  |  |                             |
|----------|--------------|--|-----------------------------|
|          | P+           |  | CH+ / Page+                 |
|          | [≡i]/[≡+]    |  | Info / Angle                |
|          | Vol+         |  | Vol+                        |
|          | P-           |  | CH- / Page-                 |
|          | Mute         |  | Mute / Dimmer               |
|          | Vol-         |  | Vol-                        |
|          | Pause        |  | Pause / Step / Freeze       |
|          | I<</[≡?]     |  | I<< / Preset-               |
|          | >>I/O/[≡x]   |  | >>I / Preset+               |
|          | <</[≡+]      |  | << / Tune-                  |
|          | Play         |  | Play / Slow                 |
|          | Stop         |  | Stop / Hold                 |
|          | >>/[≡◇]      |  | >> / Tune+                  |
|          | Red/Zoom     |  | Red / Netflix / Search      |
|          | Green/Repeat |  | Green / APP / Repeat        |
|          | Yellow/Root  |  | Yellow / YouTube / Repeat   |
|          | Blue/Title   |  | Blue / Prime Video / Random |

| Original | Replacement |
|----------|-------------|
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |

