







































































Original	Replacement	Original	Replacement
	Power		Power
	Source		AV
	TV		TV/R
	Quick		Shift + Pre Ch
	ECO		Shift + 3D
	List		List
	Vol+		Vol +
	Vol-		Vol -
	AD		Shift + Subt
	Mute		Mute
	P+		Ch +
	P-		Ch -
	Menu		Menu
	Guide		Guide
	Exit		Exit
	Back		Back
	Up		Up
	Right		Right
	Down		Down
	Left		Left
	OK		Ok
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9





Original	Replacement	Original	Replacement
0	0	0	0
[i+]	DISPLAY INFO	INFO	Info
Recall	FAV PRE-CH	PRE-CH	Pre Ch
[≡+]	SETTINGS OPT	OPT	Options
[≡◆]	SHIFT + PICTURE FORMAT	SHIFT + PICTURE FORMAT	Shift + Format
Play	PLAY MODE	PLAY MODE	Play
<<	<<	<<	<<
>>	>>	>>	>>
<<	<<	<<	<<
>>	>>	>>	>>
Stop	Stop	Stop	Stop
REC	REC MODE	REC MODE	Rec
Pause/Step	Pause	Pause	Pause
[≡?]	E-MANUAL D.MENU	D.MENU	D. Menu
[O]/[≡X]	SHIFT + TIMER AV	SHIFT + TIMER AV	Shift + AV
Text	REPEAT TEXT	TEXT	Text
3D	ECO 3D	3D	3D

Original	Replacement	Original	Replacement
[v]	HOME SMART	HOME SMART	Smart
[>]	PROG SLEEP	PROG SLEEP	Sleep
-> [/] <-	SHIFT + REPEAT TEXT	SHIFT + REPEAT TEXT	Shift + Text
V.Format	PICTURE FORMAT	PICTURE FORMAT	Format
Audio I/II	SOUND DUAL	SOUND DUAL	Dual
More Info	SHIFT + DISPLAY INFO	SHIFT + DISPLAY INFO	Shift + Info
Subtitle	AD SUBT	AD SUBT	Subt

