









































Original	Replacement
 Open/Close	 Eject / Surround
 Setup	 Setup / OPT /
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 OSC	 Fav / Marker / PC
 0	 0
 Clear	 Exit / Cancel / Clear
 MC	 Guide / EPG / -/--
 Up	 Up

Original	Replacement
 Pop Up Menu	 Menu / Home
 Left	 Left
 OK	 OK
 Right	 Right
 Return	 Back / Return
 Down	 Down
 Top Menu	 D.Menu / Top
 A-B	 Shift + Yellow / YouTube /
 Repeat	 Shift + Green / APP /
 Goto	 Text / Goto
 Display	 Display / Media
 <</<<	 << / Tune-
 Play/Pause	 Play / Slow
 >>/ >>	 >> / Tune+
 I<<	 I<< / Preset-
 Stop	 Stop / Hold
 I> I>	 Pause / Step / Freeze





Original		Replacement		Original		Replacement	
	>>		>>  / Preset+				
	Red/Program		Red / Netflix / Search				
	Green/Digest		Green / APP / Repeat				
	Yellow/Zoom		Yellow / YouTube / Repeat				
	Blue/Bookmark		Blue / Prime Video / Random				
	Subtitle		Subtitle / EQ				
	Audio		Audio / Lang I/II				
	PIP		Zoom / Size				
	PIP Audio		Sound / Title				
	Angle		Info / Angle				
	Connected		Smart / List				

