



Original	Replacement	Original	Replacement
	Power		Mute
	Source		Mute
	1		Ch +
	2		Ch -
	3		Menu
	4		Q.Menu
	5		Menu
	6		D. Menu
	7		D. Menu
	8		Back
	9		Back
	0		Exit
	[TV]		Exit
	TV/R		Up
	Pre Ch		Down
	Internet		Right
	Smart		Left
	Vol +		Ok
	Vol -		i
			Info
			Options
			Options
			Guide
			Guide
			Format
			Format
			3D
			3D





Original	Replacement	Original	Replacement
 TXT	 Text		
 Lang.	 Dual		
 Subt.	 Subt		
 [+]	 Eject		
 <<<	 <<<		
 Pause	 Pause		
 >>>	 >>>		
 Rec	 Rec		
 Play	 Play		
 Stop	 Stop		
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		

