Mandis shop

APPLE APPLE TV

Original		Replacement		Original	Replacement
	Up		Up		
	Left		Left		
	OK	OK	OK		
	Right		Right		
	Down		Down		
MENU	Menu	HOME MENU	Menu / Home		
	Play	SLOW	Play / Slow		
	Pause	STEP - FREEZE	Pause / Step / Freeze		

https://all-remotes.online/en/APPLE/1063935-79779-replacement-remote-control-for-APPLE-Apple-Tv.html