Mandis shop

LG AKB36144904

Original		Replacement	
POWER	Power	Power	Power
AUTO	Auto	Auto	Auto
RATIO	Ratio	Invert / 3D	3D / Invert
INPUT	Input	Source	Source
EXIT	Exit	Page▲ / Vol	Vol + / Page +
MENU	Menu	Menu	Menu
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
OK	OK	Enter	Enter
☼	☼	Focus / Volt	Volt / Focus
(I)	(I)	Aspect / Eco	Eco / Aspect
MODE	Mode	Mode	Mode
A.IRIS	A.Iris	Play / +	+ / Play
KEYSTONE	Keystone	Shift + ▲	Shift + Up
STILL	Still	Stop / −	- / Stop

Original		Replacement	
BLANK	Blank	Mute / Blank	Blank / Mute
PATTERN	Pattern	Video / Comp	Comp / Video
C.TEMP	C.Temp	Page▼ / Vol	Vol - / Page -
SLEEP	Sleep	Timer / Freeze	Freeze / Timer
GAMMA	Gamma	Info / Help	Help / Info

https://all-remotes.online/en/LG/1059965-21455-replacement-remote-control-for-LG-AKB36144904.html