Mandis shop

BOM003

Original	Replacement	Original	Replacement
Program	TV/Radio /		
-10/Fol-	CH- / Page-		
+10/Fol+	CH+ / Page+		
Play USB	Play / Slow		
Pause USB	Pause / Step / Freeze		
I<<	I<< / Preset-		
<<	<< / Tune-		
>>	>> / Tune+		
>>I	>>I / Preset+		
Stop	Stop / Hold		
Repeat/Random	Green / APP / Repeat		
Vol-	Vol-		
Vol+	Vol+		

https://all-remotes.online/en/BOMAN/1066556-91148-replacement-remote-control-for-BOMAN-BOM003.html