Mandis shop

AUNA ITUNER320BT

Original		Replacement	
	Power		Power
	Info	ANGLE INFO	Info / Angle
	Mode	FORMAT PICTURE	Picture / Format
	Memory	Prime Video RANDOM	Blue / Prime Video / Random
	Menu	HOME MENU	Menu / Home
	Back	RETURN BACK	Back / Return
	Up		Up
	Left		Left
	Select	OK	OK
	Right		Right
	Vol-	VOL −	Vol-
	Down		Down
	Vol+	+ VOL	Vol+
	Tuning-	TUNE-	<< / Tune-
	Tuning+	TUNE+	>> / Tune+
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+

Original		Replacement	
	Play	SLOW	Play / Slow
	Pause	STEP - FREEZE	Pause / Step / Freeze
	Mono/ST.	LANG I/II AUDIO	Audio / Lang I/II
	EQ	EQ SUBTITLE	Subtitle / EQ
	Mute	DIMMER MUTE	Mute / Dimmer
	Sleep	TIMER SLEEP	Sleep / Timer
	Alarm	NETFLIX SEARCH	Red / Netflix / Search
	Snooze	LIST SMART	Smart / List

https://all-remotes.online/en/1067152-96887-replacement-remote-control-for-AUNA-iTuner320BT.html