Mandis shop

CU- XR013

Original		Replacement		Original	Replacement
POWER	Power		Power		
VOLU	Volume-	VOL –	Vol -		
LUME +	Volume+	+ VOL	Vol +		
FUNC	Func	HOME MENU	Menu / Home		
TUN STA	Tuner Station-	TUNE-	<< / Tune-		
ER TION +	Tuner Station+	TUNE+	>> / Tune+		
S.BASS	S. Bass	LANG I/II AUDIO	Audio / Lang I/II		
DISC	Disc	Prime Video RANDOM	Blue / Prime Video / Random		
	Stop	HOLD	Stop / Hold		
	Pause	STEP-FREEZE	Pause / Step / Freeze		
	Play	SLOW	Play / Slow		
PGM	PGM	OPT-TOOLS SETUP	Setup / OPT /		
	I <<	PRESET-	I << / Preset-		
	>>I	PRESET+	>>I / Preset+		

https://al-remotes.online/en/Pioneer/1629455-replacement-remote-control-for-Pioneer-CU-XR013-A001.htm