Mandis shop

REMCON2119

Original		Replacement		Original	Replacement
ON/OFF	On/Off		Power		
Mode	Mode	FORMAT PICTURE	Picture / Format		
Fan Speed	Fan Speed	LIST SMART	Smart / List		
Up	+/Up	CH PAGE +	CH+ / Page+		
Timer	Timer	TIMER SLEEP	Sleep / Timer		
Down	-/Down	CH PAGE −	CH- / Page-		

https://all-remotes.online/en/1068077-96831-replacement-remote-control-for-REMCON2119.html