Mandis shop

RC-100

Original	Replacement
Play	Play / Slow
Rec Mute	Mute / Dimmer
<< Rew /	<< / Tune-
>> F.Fwd / Cue	>> / Tune+
Pause	Pause / Step / Freeze
Stop	Stop / Hold

Original	Replacement

https://all-remotes.online/en/Aiwa/1067224-95160-replacement-remote-control-for-Aiwa-RC-100.html