Mandis shop

VIBROSHAPER

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| | Power | | Power | | |
| | I> | | Pause / Step / Freeze | | |
| | Vel Up | | Up | | |
| | < TPO | | Left | | |
| | TPO > | | Right | | |
| | Vel Down | | Down | | |
| | M | | Menu / Home | | |
| | P | | Info / Angle | | |

https://all-remotes.online/en/Vibrolegs/1066804-96439-replacement-remote-control-for-Vibrolegs-Vibroshaper.html