Mandis shop

Yamaha FSR78

Original		Replacement		Original	Replacement
	Power		Power		
HDMI	HDMI	HDMI - SAT 0	0		
TV	TV	TV 1	1		
ANALOG	Analog	OPT-TOOLS SETUP	Setup / OPT /		
BLUETOOTH	Bluetooth	BLUETOOTH 9	9		
SURROUND	Surround	SURROUND	Eject / Surround		
STEREO	Stereo	LANG I/II AUDIO	Audio / Lang I/II		
CLEAR VOICE	Clear Voice	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
BASS EXTENSION	Bass Extension	TITLE SOUND	Sound / Title		
BLUETOOTH STANDBY	Bluetooth	SHIFT +	Shift + Power		
DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer		
SUBWOOFER +	Subwoofer +	CH PAGE +	CH+ / Page+		
VOLUME +	Volume+	VOL +	Vol +		
—	Subwoofer -	CH PAGE —	CH- / Page-		
MUTE	Mute	DIMMER MUTE	Mute / Dimmer		
—	Volume-	VOL —	Vol -		

https://al-remotes.com/en/Yamaha/1032-395-replacement-remote-control-for-Yamaha-FSR78-ZV28960.html